

CONFIGURATION WITH NEW CONFIGURATION SOFTWARE

SET LOAD IMBALANCE DETECTION + LOCAL LOAD MANAGEMENT

1	Click the [Individual Configuration] button
2	Switch on charging station
3	Wait 15 seconds
4	Press [Scan] button
5	Select radio button for load imbalance detection
6	Load imbalance detection is activated
7	Select checkbox „Local load management“
8	„Local load management“ is selected